


How to Measure Clear Roller Shades

How To Measure For Inside Mount Roller Shades




Inside mount roller shades are installed inside the window frame or casing.

Steps:

1. Measure the depth from the window casing to the glass pane. Make sure your window recess meets the minimum depth requirement for an inside mount.
2. Measure the inside narrowest width of the window casing.
3. Measure the inside tallest height from the top of the window casing.
4. Take notice that approx. 50mm will be automatically deducted from the total width provided by the customer to accommodate the hardware.

How To Measure For Outside Mount Roller Shades



For face fitting blinds, measure the outside width of the window frame.

Steps:

1. Measure the width across the top outer edges of the architrave **where the brackets will be fitted.**
2. Next, measure the hard drop from the top outside edge of the architrave to the bottom outside edge of the architrave. The length may be increased if you want the blind to drop past the bottom of your window frame.
3. To determine the width of the roller shades, make sure there is **enough flat surface for mounting hardware.**
4. If your window has no trim, add 5-7.5 cm on each side and measure the width between them in a straight line.
5. Take notice that approx. 50mm will be automatically deducted from the total width provided by the customer to accommodate the hardware.

Note:

- For accurate measurements, only use steel tape.
- Follow the width by height format (H x W) for measurements.